Technical Data Sheet


FRAMED ILLUMINATED MIRROR ILL6MIR + VT55MFXX



No.	Description	Code	Fixings Included
1	Illuminated LED mirror	ILL6MIR	YES
2	Vitoria Frame	VT55MFXX	YES







FRAME SOLD SEPARATELY

Features


- LED Technology
- Rocker switch
- IP44 Rated
- Heated demister pad (REW- 0918 size: 230x450mm)
- Painted frame VT55MFXX (sold separately)

Technical Data Sheet FRAMED ILLUMINATED MIRROR


ILL6MIR + VT55MFXX





Dimensions - Frame



Diagrams not to scale. All dimensions in mm (tolerance of +/-5mm)







*Dimensions are subject to change, customers are advised to measure actual product before commencing installation. **Fixing point dimensions are for guidance only/the positions of wall fixing must be checked when product is received.

FAQ's

Q: Is the mirror/cabinet IP44 rated?

A: Yes, it can be placed in Zone 2 and outside zones.

Q: Can the mirror be hung portrait and landscape?

A: No, portrait only.

Q: How do you fix the mirror to the wall?

A: The mirror frame has keyhole slots to be installed using the fixing pack provided. Refer to enclosed instructions for further details.

Q: What size fuse should I use?

A: We cannot recommend fuse size as each installation is different a qualified Electrician should be consulted in accordance with IEE 7671.

Technical Data Sheet

FRAMED ILLUMINATED MIRROR ILL6MIR + VT55MFXX



FAQ's

Q: What is the thickness of the mirror glass?

A: 5mm PVC back filmed.

Q: Is the mirror fitted with a mains cable?

A: Yes, the cable length is approximately 500mm (see drawing above).

Q: What is the total power consumption?

A: 35.48Watts.

Q: Does the mirror have an energy rating?

A: The mirror has an energy rating for the LED lighting used only in accordance with EU 874-2012. LED's used in this products are rated as 'A'.

Q: What is the color of the light?

A: 6000K (cool white)

Q: Does the mirror have a shaver socket?

A: No

Q: What size is the demister pad?

A: size: 230x450mm.

Q: How do I turn on the demister pad?

A: The demister pad is activated when the light on the mirror is 'ON'.

Q: Where is the Rocker switch located?

A: See previous page drawings.

Q: Can the Rocker switch be re-positioned?

A: No, the location of the IR sensor can't be changed.

Q: What is the guarantee on this product?

A: 2 years